

SCHEDA TECNICA - SUPREME

Туре	Material	Glue	Thickness	Hardness	Color	W	idth (d	cm)
Supreme :	PVC	Rubber based	0,9 mm	95 Shore A	Yellow	5	7,5	10
			•	•	Red	5	7,5	10
					White	5	7,5	10
					Blue	5	7,5	10
					Green	5	7,5	10
					Orange	5	7,5	10
					Black	5	7,5	10
					Yellow	5	7,5	10
					Red	5	7,5	10
					White	5	7,5	10
					Blue	5	7,5	10
					Green	5	7,5	10
					Orange	5	7,5	10
					Black	5	7,5	10
					Grey	5	7,5	10
					Purple	5	7,5	10
					Hi-viz Yellow	5	7,5	10
					Black / Yellow	5	7,5	10
					Red / White	5	7,5	10
					Black / White	5	7,5	10
					Yellow background	5	7,5	10

Adhesion: 1=poor, 10=super	Supreme		
Smooth metal (aluminium/iron/steel)	10		
Epoxy floor with non-skid sand	8		
Epoxy floor smooth	8		
Concrete (clean)	8		
Quarry tiles	8		
Vinyl floor	7		
Cold (-10 C) Aluminium	5		
Moist (Water) Aluminium	6		
Temperature of application (min.)	-20 C		
Temperature of application (max.)	+40 C		
Recommended temperature of installation	> + 15 C		
Minimum temperature of installation	+5 C		

5 7,5

White background

10



Chemical resistance	Property		
Weather	Good		
Mineral oils	Variable		
Vegetable oils	Good		
Cutting oil/Cooling liquid (containing compounds of esters and amines)	Good		
Alkaline liquids pH: 7 – 9.5	Good		
Powerful alkaline liquids pH: 9.5 - 14	Good		
Acids pH: 2 – 7	Good		
Powerful acids pH: 0 – 2	Good		
Disinfectants	Good		
Alcohol	Good		
Chloride solutions	Variable		
Solvents (aromatic/aliphatic)	Poor		
Halogenated carbon hydrides	Poor		
Phthalates (and related softeners)	Poor		
Acetate and aldehyde	Poor		
Ketones (acetone)	Poor		

Cleaning guidance (before installation):

The surface must be clean. Eliminate dust, dirt and oil residue.

We recommend using a powerful soap solvent. Subsequently rinse with clean warm water and wipe with a moist cloth.

Cleaning:

Dirty DMR is cleaned with warm water and soap. DMRdoes not resist powerful solvents, but resists acids and alkaline liquids.

How to remove tape from the surface:

Possible glue remnant is removed with a solvent.

- 1. Use a "Citrus Cleaner" and add some on a cloth and smear it on the glue remnant
- 2. Brush over the glue remnant with a scrubbing brush
- 3. The dissolved remnant is wiped with a dry cloth
- 4. Wash the floor surface with soap or household spirit to degrease the surface

Remember to take protective measures before the cleaning is done. Make a test with the solvent before it is used on a large area to make sure that the surface resists the solvent.

Installation:



Installation tools



Wash the surface to be striped in order to eliminate dust, dirt and oil residue. The surface must be dry before installation. Chalk out where DMR is to be laid.



Release backing successively and apply to clean surface with pressure for maximum adhesion.



For large applications it is easy to apply DMR with the Applicator.

How to cut corners.





